





Povežite opremu kao na slici:



ZyXel splitter:

 <p>Телефонный аппарат ZyXEL Универсальный телефонный сплиттер Модель AS6AB EE Не подлежит обязательной сертификации</p> <p>Annex A Annex B</p> <p>Телефонная линия Модем ADSL</p>	<p>Телефонная линия – telefonska linija što odgovara priključku „LINE”</p> <p>Модем ADSL – odgovara priključku „ADSL MODEM”</p> <p>Телефонный аппарат – telefonski aparat što odgovara priključku „PHONE”</p> <p>Ukoliko imate ISDN telefonsku liniju prekidač sa strane treba staviti u položaj za „Annex B”</p> <p>Ukoliko imate direktnu telefonsku liniju prekidač sa strane treba staviti u položaj za „Annex A”</p>
--	---

Potrebno je da pristupite ruteru tako što ćete otvoriti pretraživač i u adres bar upisati: **192.168.1.1**

<p>Za password izbrišite tačkice i ukucajete “1234” i kliknite na dugme “Login”.</p>	 <p>ZyXEL</p> <p>P660RT2</p> <p>Welcome to your router Configuration Interface.</p> <p>Enter your password and press enter or click "Login".</p> <p>Password: [.....]</p> <p>Login Cancel</p>
<p>U polje “New Password” ukucajte “admin”.</p> <p>U polje “Retype to Confirm” ukucajte “admin”.</p> <p>Kliknite na dugem “Apply”.</p>	 <p>ZyXEL</p> <p>Use this screen to change the password.</p> <p>Your router is currently using the default password. To protect your network from unauthorized users we suggest you change your password at this time. Please select a new password that will be easy to remember yet difficult for others to guess. We suggest you combine text with numbers to make it more difficult for an intruder to guess.</p> <p>Enter your new password in the two fields below and click "Apply". Otherwise click "Ignore" to keep the default password.</p> <p>New Password: [.....]</p> <p>Retype to Confirm: [.....]</p> <p>Apply Ignore</p>

Za password izbrišite tačkice i ukucajte "admin" i kliknite na dugme "Login".



ZyXEL

P660RT2


Welcome to your router Configuration Interface.
Enter your password and press enter or click "Login".

Password:|

Login Cancel

Izaberite drugu opciju "Go to Advanced setup"

Kliknite na dugem "Apply".



ZyXEL

Please select Wizard or Advanced mode

The Wizard setup walks you through the most common configuration settings. We suggest you use this mode if it is the first time you are setting up your router or if you need to make basic configuration changes.

Use Advanced mode if you need access to more advanced features not included in Wizard mode.

Go to Wizard setup
 Go to Advanced setup
 Click here to always start with the Advanced setup.

Apply Exit

Podešavanje konekcije

Izaberite u meniju opciju "Network" i podopciju "WAN".

samo za ISDN telefonsku liniju:
kod opcije "Annex" izaberite "Annex B"

U opcijama:


User name – upišite Vaš user name /korisničko ime/ sa Ugovra u obliku **username@beotel**

Password – upišite Vašu lozinku sa Ugovra (velika i mala slova su bitna)

VPI – upišite "8"

VCI - upišite "35"

Kliknite na dugem "Apply".



ZyXEL

Network > WAN > Internet Connection

Status

P660RT2

- Network
 - WAN**
 - LAN
 - NAT
- Security
- Advanced
- Maintenance

Internet Connection More Connections WAN Backup Setup

Line

Modulation Multi Mode

Annex Annex A

General

Name MyISP

Mode Routing

Encapsulation PPPoE

User Name username@beotel

Password

Service Name

Multiplexing LLC

Virtual Circuit ID

VPI 8

VCI 35

IP Address

MTU 1500

Obtain an IP Address Automatically
 Static IP Address
 IP Address 0.0.0.0

Connection

Nailed-Up Connection
 Connect on Demand Max Idle Timeout 0 sec

Apply Cancel Advanced Setup

Svetlosni indikatori (sijalice)

POWER	svetli	uređaj je uključen
	ne svetli	uređaj je isključen
ETHERNET	svetli	uključen uređaj u Ethernet port
	ne svetli	nema priključenog uređaja u Ethernet portu
DSL	ne svetli	nema ADSL signala
	treperi	sinhronizuje se
	svetli	ima ADSL signal
INTERNET	svetli (sa treperenjem)	uspostavljena internet konekcija
	ne svetli	nije uspostavljena internet konekcija